



Illustrated Parts List

Model Series

122200

TYPE NUMBERS
0110 through 0121.


TABLE OF CONTENTS

Air Cleaner	5
Blower Housing	6
Camshaft	2
Carburetor	4
Controls	5
Crankcase Cover	2
Crankshaft	2
Cylinder	2
Cylinder Head	3
Exhaust System	5
Flywheel	6
Fuel Supply	4
Governor Spring	5
Ignition	5
Kits/Gaskets – Carburetor	4
Kits/Gaskets – Engine	2
Kits/Gaskets – Valve	3
Lubrication	2
Piston Group	2
Rewind Starter	6

PRINTED IN U.S.A.



COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.










15A


1019 LABEL KIT

1058 OWNER'S MANUAL





1330 REPAIR MANUAL








358 ENGINE GASKET SET




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 3376-2 Assemblies include all parts shown in frames. 08/15/2005






Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 3376-3 Assemblies include all parts shown in frames. 08/15/2005



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
3376-4 Assemblies include all parts shown in frames. **08/15/2005**



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
3376-5 Assemblies include all parts shown in frames. 08/15/2005



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
3376-6 Assemblies include all parts shown in frames. 08/15/2005

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION		
1	699490	Cylinder Assembly	23	699488	Flywheel	59	490653	Grip-Insert		
2	399269	Kit-Bushing/Seal (Magneto Side)	24	222698	Key-Flywheel	60	490652	Grip-Starter Rope (2 Piece)		
3	★299819	Seal-Oil (Magneto Side)	25	499627	Piston Assembly (Standard)	65	699228	Screw (Rewind Starter)		
5	699486	Head-Cylinder			Note	78	699205	Screw (Flywheel Guard)		
7	★∅698210	Gasket-Cylinder Head			692789 Piston Assembly (.020" Oversize)	95A	698544	Screw (Throttle Valve)		
11	812208	Tube-Breather (Flat Panel Air Cleaner)	26	499631	Ring Set (Standard)	97A	698542	Shaft-Throttle		
12	★699485	Gasket-Crankcase			Note	98B	698551	Kit-Idle Speed		
13	699482	Screw (Cylinder Head)			692786 Ring Set (.020" Oversize)	104A	●698536	Pin-Float Hinge		
15	691686	Plug-Oil Drain (Square Head)	27	691866	Lock-Piston Pin	105	698537	Valve-Float Needle		
15A	691682	Plug-Oil Drain (Flush)	28	499423	Pin-Piston	108C	698546	Valve-Choke		
16	699835	Crankshaft Used on Type No(s). 0119.	29	690124	Rod-Connecting	117A	698670	Jet-Main (Standard)		
		Note	30	791584	Dipper-Connecting Rod	118A	698552	Jet-Main (High Altitude)		
		699443 Crankshaft Used on Type No(s). 0110, 0120.	32	691664	Screw (Connecting Rod)	121B	698567	Kit-Carburetor Overhaul		
		698879 Crankshaft Used on Type No(s). 0111, 0112, 0113, 0117, 0118.	32A	695759	Screw (Connecting Rod)	122	★●693749	Spacer-Carburetor		
		699452 Crankshaft Used on Type No(s). 0121.	33	499642	Valve-Exhaust	125A	698535	Carburetor		
17	692517	Bearing-Ball	34	499641	Valve-Intake	127C	●690727	Plug-Welch		
17A	690824	Bearing-Ball	35	691304	Spring-Valve (Intake)	130B	698543	Valve-Throttle		
18A	790337	Cover-Crankcase	36	691304	Spring-Valve (Exhaust)	133A	698539	Float-Carburetor		
20	★692550	Seal-Oil (PTO Side)	37	699661	Guard-Flywheel	137A	●●698538	Gasket-Float Bowl		
21	281658	Cap-Oil Fill	38	698557	Screw (Shut Off Valve)	141	698545	Kit-Choke Shaft		
22	699478	Screw (Crankcase Cover/ Sump)	40	692194	Retainer-Valve	146	690979	Key-Timing		
			45	690977	Tappet-Valve	155	★698214	Plate-Cylinder Head		
			46A	696813	Camshaft	161	699207	Base-Air Cleaner (Metal)		
			51	★●●∅692555	Gasket-Intake (2 Required)			163B	★●●696024	Gasket-Air Cleaner (Flat Panel Air Cleaner)
			55	791848	Housing-Rewind Starter	180	791598	Tank-Fuel (Metal)		
			58	66574	Rope-Starter (Cut to Required Length)	181	699840	Cap-Fuel Tank (Metal)		

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

122200

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
187B	791874	Line–Fuel (Molded) (Used After Code Date 05063000).	270	691027	Nut (Control Wire Casing)	427	694255	Nut (Control Bracket)
		Note	271	691028	Lever–Control	445	491588	Filter–Air Cleaner Cartridge (Flat Panel)
		693401 Line–Fuel (Molded) (Used Before Code Date 05070100).	271A	694256	Lever–Control	455	692591	Cup–Flywheel
188	699479	Screw (Control Bracket)	276A	698540	Washer–Sealing	456	692299	Plate–Pawl Friction
190B	699839	Screw (Fuel Tank)	281	790261	Panel–Control	459	281505	Pawl–Ratchet
192	694543	Adjuster–Rocker Arm	286	698611	Module–Oil Sensor	464	698550	Seal–O Ring (Fuel Shut Off Valve)
209	692571	Spring–Governor Note	300E	791595	Muffler	504	694254	Washer Set–Friction
		693206 Spring– Governor Used on Type No(s). 0118.	304	699598	Housing–Blower	505	691251	Nut (Governor Control Lever)
209A	691278	Spring–Governor	305	699480	Screw (Blower Housing)	522	697689	Plug–Dipstick/Fill
219	693578	Gear–Governor	306	693610	Shield–Cylinder	535	696263	Filter–Air Cleaner Foam
220	691724	Washer (Governor Gear)	307	699483	Screw (Cylinder Shield)	552	692346	Bushing–Governor Crank
222	699589	Bracket–Control	332	699359	Nut (Flywheel)	562	691119	Bolt (Governor Control Lever)
222C	699493	Bracket–Control	333	695711	Armature–Magneto	564	699491	Screw (Control Cover)
227	692573	Lever–Governor Control	334	699477	Screw (Magneto Armature)	564A	699206	Screw (Control Cover)
231	690718	Screw (Choke Valve)	337	491055	Plug–Spark Note	597	691696	Screw (Pawl Friction Plate)
238	691300	Valve–Cap			691043 Plug–Spark Used on Type No(s). 0113.	601	95162	Clamp–Hose
265	691024	Clamp–Casing	347	698338	Switch–Rocker	604	697326	Cover–Control
267	699492	Screw (Casing Clamp)			Note	608	791670	Starter–Rewind
268	691025	Casing–Control Wire (72" Long) (Cut to Required Length)			697854 Switch–Rocker Used on Type No(s). 0110, 0112, 0113, 0117, 0118.	613	699209	Screw (Muffler)
269	691026	Wire–Control (78" Long) (Cut to Required Length)	356	692602	Wire–Stop	615	692576	Retainer–Governor Shaft
			356A	695630	Wire–Stop	616	692547	Crank–Governor
			358	699638	Gasket Set–Engine	619	699230	Screw (Cylinder Head Plate)
			363	19069	Puller–Flywheel	621	692310	Switch–Stop
			364	695693	Terminal–Oil Plug	632	693408	Spring/Link– Mechanical Governor
			365	699484	Screw (Carburetor)			
			383	19374	Wrench–Spark Plug			
			415	693463	Plug			
			425	699208	Screw (Air Cleaner Cover)			

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

⊘ Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

3376–8

Assemblies include all parts shown in frames.

08/15/2005

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
633B	●690998	Seal-Choke/Throttle Shaft	843A	695588	Sleeve-Lever	987	698556	Seal-Throttle Shaft
635	692927	Boot-Spark Plug	851	493880	Terminal-Spark Plug	993	∅694088	Gasket-Cylinder Head Plate
643	696264	Retainer-Air Filter	868	★∅692044	Seal-Valve	1005	692592	Fan-Flywheel
652	699755	Screw (Support Bracket)	883	★691893	Gasket-Exhaust	1019	694852	Kit-Label
652A	699230	Screw (Support Bracket)	890	790203	Bracket-Control	1022	★∅691890	Gasket-Rocker Cover
663	699206	Screw (Control Panel)	914	699481	Screw (Rocker Cover) (Bottom)	1023	791585	Cover-Rocker Arm
668	694257	Spacer	914A	692557	Screw (Rocker Cover) (Top)	1026	790287	Rod-Push
689	691855	Spring-Friction	914B	697551	Screw (Rocker Cover) (Center)	1029	691230	Arm-Rocker
692	690572	Spring-Detent	958	698549	Valve-Fuel Shut Off (Plastic)	1034	691343	Guide-Push Rod
718	690959	Pin-Locating	967	493537	Filter-Pre Cleaner (Flat Panel)	1052	790141	Sensor-Oil
741	695087	Gear-Timing	968	692584	Cover-Air Cleaner (Flat Panel)	1058	276355	Owner's Manual
742	692564	Retainer-E Ring	971	690370	Screw (Air Cleaner Base To Carburetor)	1070	699201	Screw (Flywheel Fan)
746	692566	Gear-Idler	975A	698541	Bowl-Float	1095	698215	Gasket Set-Valve
773	694258	Retainer	977B	698568	Gasket Set-Carburetor	1210	791849	Pulley/Spring Assembly (Pulley)
799	699202	Screw (Oil Sensor)				1211	791849	Pulley/Spring Assembly (Spring)
819	699233	Screw (Muffler Bracket)				1305	699691	Screw (Oil Sensor Module)
830	694544	Stud-Rocker Arm				1330	272147	Repair Manual
832D	791600	Guard-Muffler				1345	699887	Filter-Filler Neck
836E	699491	Screw (Muffler Guard)						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.